



Premium Multi-Purpose Detailing Buffing Kit Instructions (English):

1. Vehicle should be in a garage or in the shade, out of direct sunlight.
Wash surface where blemish is with soap and water and wipe dry.
2. Attach arbor to the 3-inch backing plate, turning it clockwise until tight.
Then tighten lock nut clockwise to prevent arbor from coming off during use, attach to a drill or pistol grip polisher.
3. Attach the purple wool pad to the 3-inch backing plate. Put a dime-sized amount of polishing compound onto blemish. (compound should be capable of removing 1500 grit sand scratches). Place the wool pad directly onto the polishing compound and start polishing with an up and down, side to side motion. Do this until compound is almost gone.
4. Wipe area with the blue microfiber towel, proceed to next step if blemish area appearance is acceptable. If not, repeat last step.
5. Remove purple wool pad and attach the soft black foam pad. Apply less than a dime-sized amount of glaze polish onto polishing area. Place foam pad directly onto the polish and start polishing with an up and down, side to side motion. Do this until polish is almost gone.
6. Lastly, there are 2 options that can be used. One is removing the black foam pad and attaching the thin black microfiber pad and polish remaining polish residue off surface. The other option is to wipe polish residue off with the blue microfiber towel.

* Buffing pads can be cleaned for re-use. Wool and microfiber can be machine washed and air dried. Foam pad can be hand washed with soap and water and air dried.